



# Instructions



## Setting up

The portable screen holds itself open. All you need is something to lean it against.

This eliminates the need for a frame with a stand. The frame stretches the fabric automatically preventing large wrinkles, which could create hard-to-remove shadows.

If you do not have extensive lighting equipment, you can take the screen outside and shoot in the shade.



## Folding the screen

First bring the screen's corner to your chest.

Then fold that corner over to the opposite corner.

Reverse your left hand.

Twist your hand back around from the circle.



Fold that circle under the circle formed in your right hand.

Adjust the circles until they are two equal circles that are on top of each other.

Put the screen back into it's case.

**For a video of these folding instructions please visit youtube and type:**

**You**  **How to fold a green screen MTS into the search**

Or visit:

[http://www.youtube.com/watch?v=7\\_imuJsAqAE](http://www.youtube.com/watch?v=7_imuJsAqAE)



**1. The stiffner comes in two parts**



**2. Join the two parts**



**3. Attach the notches to the wire frame.**



**4. Stiffner attached to the screen.**

## Using the Stiffner

If you feel you need a bit of extra stiffness then use the supplied stiffener.

The stiffener comes in two parts.

Join the two halves and make sure the notches are facing up.

Attach the notches to the spring in the screen and then use the wing nut to hold it in place.

The stiffner will bow slightly to give the fabric extra stretch. If it bows too much, make sure the two halves are all the way in the plastic sleeve.

**For more information please see the manufacturer's website:**

<http://www.greenscreenwizard.com/Popup5x7.aspx>